







ELFY USB


ELFY USB


ELFY USB	#	W	K	lm	
	4580421	3,5	2700	210	-



ELFY USB	#	W	K	lm	
	4580423	3,5	2700	210	-



ELFY USB	#	W	K	lm	
	45804237	3,5	2700	210	-



Touch dim

